



- ① THRIVE EVO™ RECEIVER. SECURE TO THE UNDERSIDE OF A VALVE BOX LID WITH SUPPLIED STAINLESS STEEL FASTENERS, WASHERS, AND NUTS.
- ② CONNECT UP TO FOUR NEW OR EXISTING REMOTE CONTROL VALVES TO THE RECEIVER'S FIELD WIRES.
- ③ REMOVE AND REPLACE THE AC SOLENOID WITH A DC LATCHING SOLENOID COMPATIBLE WITH THE MANUFACTURER OF THE REMOTE CONTROL VALVE.
- ④ CONNECT PILOT AND COMMON WIRES WITH SUPPLIED DB0/B CONNECTORS.
- ⑤ NEW OR EXISTING REMOTE CONTROL VALVE.

○ THRIVE EVO™ RECEIVER
NOT TO SCALE