

## THRIVE RECEIVER™:

1


### Locate Valve Box

- Lift and rotate the lid so the receiver is parallel to the ground plane

2

### Press Power Button

- Press power button to turn the receiver OFF



## THRIVE TRANSMITTER™:

1


### Locate Transmitter

- Locate the transmitter located near your controller. Open the door

2

### Press Power Button

- Press power button and the LED light will extinguish



## NEED HELP?

Scan the QR code for more detailed information  
Escanea el código QR para información en español

